


## Overview and Specification




Stick switch with pot

Size:  $\Phi 11.5 \times 41.1$

Red: VCC

Yellow: SIGNAL

Black: GND




Stick switch with 2-position switch

Size:  $\Phi 11.5 \times 50$

Red: SIGNAL

Yellow: SIGNAL




Stick switch with push button

Size:  $\Phi 11.5 \times 36$

Red: SIGNAL

Yellow: SIGNAL

## Suggested Installation to the Switch Board of FrSky Taranis X9E



Joystick with controller	Stick switch with 2-pos switch	Stick switch with push button
F1/F2/F3/F4/RS/LS (GND SIGNAL VCC from top to button)	SWF/SWH (SIGNAL SIGNAL X from top to button)	SWF/SWH (SIGNAL SIGNAL X from top to button)

Refer to [www.frsky-rc.com](http://www.frsky-rc.com) for detailed installation steps.