




INSTALL GEAR AS FAR FORWARD AS POSSIBLE. MOUNTING STYLE AND LOCATION IS UP TO THE BUILDER. YOU CAN PLACE THE SERVOS SIDE BY SIDE OR ONE IN FRONT OF THE OTHER.




BOLT ON WING



ZEPHYR	
DESIGNS	
BY	REVISION A
DESIGNED BY PAUL MASURA	06/10/13
DRAWN BY BRIAN LAIRD	CONCEPTUAL DESIGN BY RALPH ROBERTS





TO PROPERLY SHAPE THE AILERON TAPE IT TO THE WING AS SHOWN. MAKE SURE IT IS FLUSH WITH THE BOTTOM WING SKIN AS SHOWN ABOVE. PLACE THE WING ON THE EDGE OF A HARD FLAT SURFACE. USING A FLAT SANDING BLOCK WITH ROUGH SANDPAPER (50 OR 60 GRIT) SAND THE TOP OF THE AILERON UNTIL IT IS FLUSH WITH THE TOP SKIN. MAKE SURE THE TRAILING EDGE OF THE AILERON IS SANDED TO ABOUT 1/32" THICK. IF THE BOTTOM NEEDS SANDING DO IT ALSO. WHEN FINISHED FINE SAND TO DESIRED SMOOTHENESS. CUT AWAY SECTION FOR THE TORQUE RODS AND INSTALL THEM. BEVEL THE LEADING EDGE OF THE AILERON PORTION.



ZEPHYR
 BY **PD DESIGNS**
 DESIGNED BY PAUL MASURA REVISION **A**
 DRAWN BY BRIAN LAIRD 06/10/13
 CONCEPTUAL DESIGN BY RALPH ROBERTS

NOTE: MAKE ALL TAIL SURFACES
FROM 3/16" SHEET BALSA



WING TIP
TEMPLATE